WOODEN CAMERA

EASY TOP / EASY TOP X

1 Gather camera, Torx, Metric, and SAE allen set, and included components.

2 Use T9 Torx wrench to remove (4) screws from top of camera.

3 Remove plastic vent cover and set aside.

4 Install (2) 1/4-20 socket cap screws in corresponding holes.

5 Install (4) M4 button head screws in corresponding holes.

6 Keep plastic vent cover and screws in secure location for future use.